

SYSTEM	SYSTEM TYPE	READ FAULTS	ERASE FAULTS	LIVE DATA
ENGINE	DIESEL BOSCH EDC 15 (mot. 1.9 '99)	√	√	
	DIESEL BOSCH EDC 15 CF3 (mot. 1.9/2.4)	√	√	√
	DIESEL BOSCH EDC 15 CF3 (mot. 2.8)	√	√	√
	DIESEL BOSCH EDC 15 PSA (mot. 2.0 TD)	√	√	
	DIESEL LUCAS EPIC DCU3F	√	√	√
	HITACHI EOBD	√	√	
	HITACHI MPI (mot. 1.8 16v)	√	√	√
	MARELLI IAW 4.8P	√	√	
	MARELLI IAW 49F (1.2 8v engine)	√	√	√
	MARELLI IAW 49F (1.6 16v engine)	√	√	√
	MARELLI IAW 4AF/4EF/59F/5AF EOBD	√	√	
	MARELLI IAW 4AF/4EF/59F/5AF Outside ECC	√	√	
	MARELLI IAW 4GF (Bi-Power)	√	√	
	MARELLI IAW 4GF (Blu-Power)	√	√	
	MARELLI IAW 59F (1.2 8v engine)	√	√	√
	MOTRONIC M 1.5.5	√	√	√
	MOTRONIC M 1.5.5 (1.2 16V engine)	√	√	√
	MOTRONIC M 1.5.5 (TS '98 engine)	√	√	√
	MOTRONIC ME 2.1 (V6 2.0 TB engine)	√	√	
	MOTRONIC ME 2.1 (V6 2.5 / 3.0 engine)	√	√	√
	MOTRONIC ME 3.1 (2.0 / 2.4 20v engine) Outside CEE	√	√	
	MOTRONIC ME 3.1 (2.0 20v engine)	√	√	√
	MOTRONIC ME 3.1 (V6 engine) Outside CEE	√	√	
	MOTRONIC ME 3.1 EOBD (2.0 / 2.4 20v engine)	√	√	
	MOTRONIC ME 3.1 EOBD (V6 engine)	√	√	
	MOTRONIC ME 7.3 H4	√	√	√
	MOTRONIC ME 7.3 H4 EOBD	√	√	
	MOTRONIC ME 7.3.1 EOBD	√	√	
	MOTRONIC ME 7.3.1 Outside CEE	√	√	
	MOTRONIC ME 7.3.1 Outside CEE (2 lambda)	√	√	
	DIESEL BOSCH EDC 15 (1.9 TD id)	√	√	√
	DIESEL BOSCH EDC 15 (2.4 TD id)	√	√	√
	MARELLI 6JD CF3	√	√	√
MARELLI 6JF CF3	√	√	√	

SYSTEM	SYSTEM TYPE	READ FAULTS	ERASE FAULTS	LIVE DATA
GEAR BOX	AISIN Q-SYSTEM AUTOMATIC GEARBOX	√	√	
	FUJI SG-CVT3 AUTOMATIC GEARBOX	√	√	
	MARELLI SELESPEED AUTOMATIC GEARBOX	√	√	√
	MARELLI SELESPEED CFC 208 F AUTOMATIC GEARBOX	√	√	
	SIEMENS AL4 TA 2000 AUTOMATIC GEARBOX	√	√	

SYSTEM	SYSTEM TYPE	READ FAULTS	ERASE FAULTS	LIVE DATA
ABS	ABS BOSCH 5.7	√	√	√
	ABS BOSCH 5.7 ASR / TC	√	√	
	ABS BOSCH 5.7 VDC	√	√	
	ABS BOSCH 5.7 VDC (166)	√	√	
	ABS LUCAS EBC 430	√	√	√
	ABS BOSCH 8	√	√	

SYSTEM	SYSTEM TYPE	READ FAULTS	ERASE FAULTS	LIVE DATA
SRS	AIRBAG ALLIED MY 97 (2F-2P)	√	√	
	AIRBAG ALLIED MY 97 (2F-2P-2L-2T-I)	√	√	
	AIRBAG ALLIED MY 97 (2F-2P-2L-I)	√	√	
	AIRBAG ALLIED MY 97 (2F-2P-2L-I-S)	√	√	
	AIRBAG ALLIED MY 97 (2F-2P-2L-S)	√	√	
	AIRBAG ALLIED MY 97 (2F-2P-I)	√	√	
	AIRBAG ALLIED MY 97 (2F-2P-I-S)	√	√	
	AIRBAG ALLIED MY 97 (2F-2P-S)	√	√	
	AIRBAG AUTOLIV ACU	√	√	
	AIRBAG AUTOLIV MY99 (1F - 2P)	√	√	
	AIRBAG AUTOLIV MY99 (2F - 2P - 2L - I)	√	√	
	AIRBAG AUTOLIV MY99 (2F - 2P - I)	√	√	
	AIRBAG BREED MY 97 (1F-2P)	√	√	
	AIRBAG BREED MY 97 (2F)	√	√	
	AIRBAG BREED MY 97 (2F-2L)	√	√	
	AIRBAG BREED MY 97 (2F-2L-S)	√	√	
	AIRBAG BREED MY 97 (2F-2P-2L)	√	√	
	AIRBAG BREED MY 97 (2F-2P-2L-S)	√	√	
	AIRBAG BREED MY 97 (2F-S)	√	√	
	AIRBAG BREED MY 97 (3F-2L-I)	√	√	
	AIRBAG BREED MY 97 (3F-I)	√	√	
	AIRBAG TRW MY 97 (2F - I)	√	√	
	AIRBAG TRW MY 97 (2F)	√	√	
	AIRBAG TRW MY 97 (2F-2L)	√	√	
	AIRBAG TRW MY 97 (2F-2L-I)	√	√	
	AIRBAG TRW MY 97 (2F-2L-I-S)	√	√	
	AIRBAG TRW MY 97 (2F-2L-S)	√	√	
	AIRBAG TRW MY 97 (2F-2P)	√	√	
	AIRBAG TRW MY 97 (2F-2P-2L)	√	√	
	AIRBAG TRW MY 97 (2F-2P-2L-2S)	√	√	
	AIRBAG TRW MY 97 (2F-2P-2L-I)	√	√	
	AIRBAG TRW MY 97 (2F-2P-2L-S)	√	√	
	AIRBAG TRW MY 97 (2F-2P-I)	√	√	
	AIRBAG TRW MY 97 (2F-2P-I-S)	√	√	
	AIRBAG TRW MY 97 (2F-2P-S)	√	√	
	AIRBAG TRW MY 97 (2F-I-S)	√	√	
AIRBAG TRW MY 97 (2F-S)	√	√		