

MODEL	SYSTEM		DTC	Live Data	Actuation Test	ECU Info	
Musso	ENGINE	3.2 DOHC A/T	√	√	√		
		3.2 DOHC M/T	√	√	√		
		3.2 DOHC A/T, LEAD	√	√	√	√	
		3.2 DOHC M/T, LEAD	√	√	√	√	
		2.3 DOHC A/T	√	√	√	√	
		2.3 DOHC M/T	√	√	√	√	
		2.3 DOHC ASC	√	√	√	√	
		2.0 DOHC A/T	√	√	√	√	
		2.0 DOHC M/T	√	√	√	√	
		2.0 DOHC ASC	√	√	√	√	
		2.3 MSE	√	√	√		
		3.2 MSE	√	√	√		
	TCU			√	√		
	ABS	ABS 5.0		√	√	√	
		ABS-ABD 5.0		√	√	√	
		ABS-EBD 5.3		√	√	√	
		ABD-EBD 5.3		√	√	√	
	ECS			√	√	√	
	SRS			√			
TOD			√				
TCCU			√				
ISTANA	ENGINE	ABS 5.0	√	√	√		
Korando	ENGINE	3.2 DOHC A/T	√	√	√	√	
		3.2 DOHC M/T	√	√	√	√	
		3.2 DOHC A/T, LEAD	√	√	√	√	
		3.2 DOHC M/T, LEAD	√	√	√	√	
		2.3 DOHC A/T	√	√	√	√	
		2.3 DOHC M/T	√	√	√	√	
		2.3 DOHC ASC	√	√	√	√	
		2.0 DOHC A/T	√	√	√	√	
		2.0 DOHC M/T	√	√	√	√	
		2.0 DOHC ASC	√	√	√	√	
		2.3 MSE	√	√	√		
		3.2 MSE	√	√	√		
	TCU			√	√		
	ABS	ABS 5.0		√	√	√	
		ABS-ABD 5.0		√	√	√	
		ABS-EBD 5.3		√	√	√	
		ABD-EBD 5.3		√	√	√	
	ECS			√	√	√	
	SRS			√			
TOD			√				
TCCU			√				
Chairman	ENGINE	3.2 (VDO)	√	√	√		
		2.8 (VDO)	√	√	√		
		2.3 (VDO)	√	√	√		
		3.2 (BOSCH)	√	√			
	TCU	BTRA TCU		√	√		
		NAG TCU		√	√		
		DC 5 A/T(T-TRONIC)		√	√		
	ABS	ABS 5.3		√	√	√	
		ABD 5.3		√	√	√	
		ASR 5.3		√	√	√	
		TEVES(ABS/ESP)		√	√	√	
		TEVES(ABS)		√	√	√	
	ECS			√	√		

Chairman	SRS		√			
Rexton	ENGINE	2.3 MSE	√	√	√	
		3.2 MSE	√	√	√	
		DSL D27DT	√	√	√	
	TCU	BTRA 4 A/T	√	√		
		DC 5 A/T(T-TRONIC)	√	√		
	ABS	BOSCH(ABS 5.3)	√	√	√	
		TEVES(ABS/ESP)	√	√	√	
		TEVES(ABS)	√	√	√	
	SRS		√			
	TOD	구형 TOD	√			
		신형 TOD(DI 엔진 적용차량)	√	√		
TCCU	구형 TCCU	√				
	신형 TCCU(DI 엔진 적용차량)	√	√			
Rodius	ENGINE	DSL D27DT	√	√	√	
	TCU		√	√		
	ABS	TEVES(ABS/ESP)	√	√	√	
		TEVES(ABS)	√	√	√	
	SRS		√			
	TOD		√	√		
	TCCU		√	√		